

Bryant Consultants

Concerned About Preparing

Your Equipment For A Temporary Practice Closure?



Here is a helpful checklist to help guide you through the process. Special thanks to Benco Dental for the information:

Your service team can help your offices to restart the equipment when it is time to do so.

- WATER BOTTLE:** Remove, empty, replace, run system to purge water from unit lines; remove water bottle, let air dry
- AIR COMPRESSOR:** Power down and release all air; drain tanks where applicable
- VAC LINES:** Flush all vac lines; replace sediment filters and all disposable traps on units
- AMALGRAM SEPARATORS:** Replace amalgam separators due to prophylaxis paste hardening
- DRY VAC:** Power down and...
- Midmark Power and G Vac:** If cutting main power, add WD-40 to pump drive piston to prevent lockup. If leaving power on and newer style system will autorun every so often to prevent lockup.
- RamVacs:** Remove air filter to release pressure. Can hydro lock from oil drip? This is normal as motor overloads may trip on startup. Kill voltage to system.
- Vac Systems:** Clean out tanks where applicable.
- Mohave Vacs:** Leave breakers on or MMC can risk serious errors
- WET VACS:** Turn off water supply after flushing lines and turn off the power
- AUTOCLAVES:** Clean and drain; do not replace water; let air dry
- HYDRIM:** Remove soap/salt and solution and run shipping cycle
- DISTILLERS:** Empty all distillers and let dry
- WATER PURIFICATION SYSTEMS:** Shut down water and purge with air until operatories and all faucets run dry
- CHAIRS:** Leave chairs in upright position as high as they will go
- HANDPIECES:** Oil all handpieces; clean and lube all HVE and SE handles
- PLASTER TRAPS:** Remove and discard
- COMPUTER SYSTEMS:** Complete backup on removable hard drive; take to a safe location offsite; power down all computers, servers, switches, etc.
- ULTRASONICS:** Drain and clean; let air dry
- WATER COLLECTION CANISTERS:** Empty all on cassette sterilizers

- MODEL TRIMMERS:** Run water for a period of 10 minutes with unit left on to clean wheel as well as flush all drain lines
- DUST COLLECTOR FILTERS:** Replace all in lab areas
- AIRLINES:** Bleed all airlines in operatories and lab areas
- MILLS:** Thoroughly clean; drain coolant water
- 3D PRINTERS:** Remove all resin in machine and clean

Contact Bryant Consultants if you have questions or need assistance:

(877) 768-4799

4889 Eagle Pointe Dr

info@bryantconsultants.com

bryantconsultants.com

